
## **IMAGE CAPTIONER**

Name: Appasamudram Naga Mohith

Register No: 122003032

## Logic:



## Dataset used:

https://github.com/jbrownlee/Datasets/releases/download/Flickr8k/Flickr8k\_Dataset.zip https://github.com/jbrownlee/Datasets/releases/download/Flickr8k/Flickr8k\_text.zip

Environment: Google Colab

### Python code:

from google.colab import drive drive.mount('/content/drive')

!unzip "/content/drive/MyDrive/Image Captioning/Flickr8k\_Dataset.zip" !unzip "/content/drive/MyDrive/Image Captioning/Flickr8k\_text.zip"

### # Importing libraries

import numpy as np
import pandas as pd
from time import time
import matplotlib.pyplot as plt
import tensorflow as tf

from tensorflow.keras.layers import (Input,Flatten,TimeDistributed,RepeatVector,Reshape,

Dense, LSTM, Activation, Dropout, Batch Normalization,

concatenate, Embedding, add)

from tensorflow.keras.models import Model,Sequential

from tensorflow.keras.preprocessing.image import load img,img to array

from tensorflow.keras.preprocessing.sequence import pad sequences

from tensorflow.keras.optimizers import Adam,RMSprop

from tensorflow.keras.applications import MobileNet,InceptionV3,VGG16

from tensorflow.keras.applications.mobilenet import preprocess input as preMobile

from tensorflow.keras.applications.inception\_v3 import preprocess\_input as preInception

from tensorflow.keras.applications.vgg16 import preprocess\_input as preVgg

from tensorflow.keras.utils import to categorical

```
import os
import string
import glob
import pickle
from PIL import Image
from tqdm import tqdm
```

```
START = "startseq"

STOP = "stopseq"

EPOCHS = 20
```

```
def hms string(sec elapsed):
```

```
h = int(sec_elapsed / (60 * 60))

m = int((sec_elapsed % (60 * 60)) / 60)

s = sec_elapsed % 60
```

return  $f''\{h\}:\{m:>02\}:\{s:>05.2f\}"$ 

#### # Data Preprocessing

```
null_punct = str.maketrans(",",string.punctuation)
look up = dict()
file = open("/content/Flickr8k.token.txt",'r')
maxlength = 0
for line in file.read().split('\n'):
 if len(line)<2:
  continue
 words = line.split()
 photoid,caption=words[0],words[1:]
 photoid = photoid.split('#')[0]
 # Cleaning the captions
 caption = [word.lower() for word in caption]
 caption = [word.translate(null punct) for word in caption]
 caption = [word for word in caption if len(word)>1]
 caption = [word for word in caption if word.isalpha()]
 maxlength = max(len(caption), maxlength)
 caption = ' '.join(caption)
 if photoid not in look up:
  look up[photoid] = list()
 look up[photoid].append(caption)
print(f'LookUp Table i.e photo-to-caption mapping size : {len(look up)}')
vocabulary = set()
                    # a new vocabulary
for key in look up:
 [vocabulary.update(d.split()) for d in look up[key]]
print(f'Vocabulary size : {len(vocabulary)}')
print(f'Max Caption Length : {maxlength}')
data = pd.DataFrame(look up.items())
data.iloc[0,1]
```

```
img = glob.glob(os.path.join('/content/Flicker8k_Dataset','*.jpg'))
len(img)
# Preparing Training Dataset
train images = []
file = open('/content/Flickr 8k.trainImages.txt')
for line in file.read().strip().split('\n'):
 if len(line)<2:
  continue
 train images.append(line)
file.close()
test images = []
file = open('/content/Flickr 8k.testImages.txt')
for line in file.read().strip().split('\n'):
 if len(line)<2:
  continue
 test images.append(line)
file.close()
dev images = []
file = open('/content/Flickr 8k.devImages.txt')
for line in file.read().strip().split('\n'):
 if len(line)<2:
  continue
 dev images.append(line)
file.close()
print(f#Train Images = {len(train images)}')
print(f#Test Images = {len(test images)}')
print(f#Dev Images = {len(dev_images)}')
```

```
train dataset = dict()
for photoid in train images:
 if len(photoid)<2:
  continue
 train dataset[photoid] = list()
 captions = look_up[photoid]
 for caption in captions:
  caption = START + " " + caption +" "+STOP
  train dataset[photoid].append(caption)
print(f'Train Dataset Ready !! {len(train dataset)} images')
len(train dataset)
for k,v in train dataset.items():
 print(k)
 for val in v:
  print(val)
 break
traindata = pd.DataFrame(train dataset.items())
traindata.head()
# Encoding train images
#encode_model = MobileNet(weights='imagenet',include_top=False)
#WIDTH,HEIGHT,OUTPUT DIM = 224,224,50176
encode model = InceptionV3(weights='imagenet')
encode_model = Model(encode_model.input,encode_model.layers[-2].output)
WIDTH = 299
HEIGHT = 299
OUTPUT DIM = 2048
```

```
encode model.summary()
def encodeimage(img):
 img = img.resize((WIDTH,HEIGHT),Image.ANTIALIAS)
 X = img to array(img)
 X = np.expand_dims(img,axis=0)
 \#X = preMobile(X)
 X = preInception(X)
 X = encode model.predict(X)
 X = np.reshape(X,OUTPUT DIM)
 return X
start = time()
train encodings = dict()
for photoid in train images:
 if len(photoid)<2:
  continue
 path = '/content/Flicker8k Dataset/' + photoid
 train image = load img(path,target size=(HEIGHT,WIDTH))
 train encodings[photoid] = encodeimage(train image)
with open('Train Images encoding inception.pkl','wb') as fp:
 pickle.dump(train encodings,fp)
print(f\nGenerating training set took: {hms string(time()-start)}')
with open('/content/drive/MyDrive/Image
Captioning/Train_Images_encoding_inception.pkl','wb') as fp:
 pickle.dump(train encodings,fp)
len(train encodings)
```

```
train enc = pd.DataFrame(train encodings.items())
train enc.iloc[0,1].shape
start = time()
test encodings = dict()
for photoid in test images:
 if len(photoid)<2:
  continue
 path = '/content/Flicker8k Dataset/' + photoid
 test image = load img(path,target size=(HEIGHT,WIDTH))
 test encodings[photoid] = encodeimage(test image)
with open('Test Images encoding inception.pkl','wb') as fp:
 pickle.dump(test encodings,fp)
print(f\nGenerating test set took: {hms string(time()-start)}')
with open('/content/drive/MyDrive/Image
Captioning/Test Images encoding inception.pkl','wb') as fp:
 pickle.dump(test_encodings,fp)
all train captions = list()
for photoid in train dataset:
 for cap in train dataset[photoid]:
  all_train_captions.append(cap)
len(all train captions)
threshold = 10
word count = dict()
for cap in all train captions:
 for w in cap.split(' '):
  word count[w] = word count.get(w,0) + 1
vocab = [w for w,count in word count.items() if count>threshold]
```

```
print('preprocessed words %d ==> %d' % (len(word count), len(vocab)))
idxtoword = \{\}
wordtoidx = \{\}
ix = 1
for w in vocab:
 wordtoidx[w] = ix
 idxtoword[ix] = w
 ix += 1
vocabsize = len(idxtoword) + 1
vocabsize
maxlength = 34 \# (32+2)
"""# Data Generator"""
def data generator(descriptions, photos, wordtoidx,max length, num photos per batch):
 # x1 - Training data for photos
 # x2 - The caption that goes with each photo
 # y - The predicted rest of the caption
 x1, x2, y = [], [], []
 n=0
 while True:
  for key, desc list in descriptions.items():
   n+=1
   photo = photos[key]
   # Each photo has 5 descriptions
    for desc in desc list:
    # Convert each word into a list of sequences.
     seq = [wordtoidx[word] for word in desc.split(' ') \
         if word in wordtoidx]
     # Generate a training case for every possible sequence and outcome
```

```
in seq, out seq = seq[:i], seq[i]
     in seq = pad sequences([in seq], maxlen=max length)[0]
     out seq = to categorical([out seq], num classes=vocabsize)[0]
     x1.append(photo)
     x2.append(in seq)
     y.append(out_seq)
   if n==num photos per batch:
    yield ([np.array(x1), np.array(x2)], np.array(y))
    x1, x2, y = [], [], []
    n=0
"""# Loading Glove Vectors"""
f = open('/content/glove.6B.200d.txt',encoding="utf-8")
embeddings index = \{\}
for line in tqdm(f):
  values = line.split()
  word = values[0]
  coefs = np.asarray(values[1:], dtype='float32')
  embeddings index[word] = coefs
f.close()
print(fFound {len(embeddings index)} word vectors.')
"""# Building the Neural Network
,,,,,,
embedding dim = 200
# Get 200-dim dense vector for each of the 10000 words in out vocabulary
embedding matrix = np.zeros((vocabsize,embedding dim))
```

for i in range(1, len(seq)):

```
for word, i in wordtoidx.items():
 embedding vector = embeddings index.get(word)
 if embedding vector is not None:
  embedding matrix[i] = embedding vector
embedding matrix.shape
inputs1 = Input(shape=(OUTPUT_DIM,))
fe1 = Dropout(0.5)(inputs1)
fe2 = Dense(256,activation='relu')(fe1)
inputs2 = Input(shape=(maxlength,))
se1 = Embedding(vocabsize,embedding dim,mask zero=True)(inputs2)
se2 = Dropout(0.5)(se1)
se3 = LSTM(256)(se2)
decoder1 = add([fe2,se3])
decoder2 = Dense(256,activation='relu')(decoder1)
outputs = Dense(vocabsize,activation='softmax')(decoder2)
caption model = Model(inputs=[inputs1,inputs2],outputs=outputs)
caption model.summary()
caption model.layers[2]
caption model.layers[2].set weights([embedding matrix])
caption_model.layers[2].trainable=False
caption model.compile(loss='categorical crossentropy',optimizer='adam',metrics=[('accuracy
')])
caption model.summary()
num pics per batch = 3
```

```
steps = len(train dataset)//num pics per batch
start = time()
for i in tqdm(range(EPOCHS*2)):
 generator =
data generator(train dataset,train encodings,wordtoidx,maxlength,num pics per batch)
 caption model.fit generator(generator,epochs=1,steps per epoch=steps,verbose=1)
caption model.optimizer.lr = 1e-4
num_pics_per_batch = 6
steps = len(train dataset)//num pics per batch
for i in range(EPOCHS):
 generator =
data generator(train dataset,train encodings,wordtoidx,maxlength,num pics per batch)
 caption model.fit generator(generator,epochs=1,steps per epoch=steps,verbose=1)
caption model.save('cpmodel.h5')
caption model.save weights('cpmodelweights.h5')
print(f"\Training took: {hms string(time()-start)}")
def generateCaption(photo):
  in text = START
  for i in range(maxlength):
    sequence = [wordtoidx[w] for w in in text.split() if w in wordtoidx]
    sequence = pad sequences([sequence], maxlen=maxlength)
    yhat = caption model.predict([photo,sequence], verbose=0)
    yhat = np.argmax(yhat)
    word = idxtoword[yhat]
    in_text += ' ' + word
    if word == STOP:
       break
  final = in text.split()
  final = final[1:-1]
```

```
final = ''.join(final)
return final

caption_model.save('/content/drive/MyDrive/Image Captioning/cpmodel.h5')

caption_model.save_weights('/content/drive/MyDrive/Image
Captioning/cpmodelweights.h5')

for i in range(20):
    pic = list(test_encodings.keys())[100+i]
    image = test_encodings[pic].reshape((1,OUTPUT_DIM))
    path = '/content/Flicker8k_Dataset/' + pic
    print(path)
    X = plt.imread(path)
    plt.imshow(X)
    plt.show()
    print("Caption: ",generateCaption(image))
```

## OUTPUT

/content/Flicker8k\_Dataset/3344233740\_c010378da7.jpg






Caption: basketball player in white uniform is trying to block player in white

/content/Flicker8k\_Dataset/3110649716\_c17e14670e.jpg



Caption: man in black coat and cap talks to woman in black coat /content/Flicker8k\_Dataset/2723477522\_d89f5ac62b.jpg



Caption: two dogs are running in the grass

## /content/Flicker8k\_Dataset/2218609886\_892dcd6915.jpg




Caption: man in black shirt and cast smokes cigarette

/content/Flicker8k\_Dataset/2435685480\_a79d42e564.jpg




Caption: man in red shirt and jeans is standing on the side of rock face

/content/Flicker8k\_Dataset/2654514044\_a70a6e2c21.jpg



Caption: brown dog is running through the grass

/content/Flicker8k\_Dataset/311146855\_0b65fdb169.jpg




Caption: man in red shirt and jeans is dancing

/content/Flicker8k\_Dataset/3385593926\_d3e9c21170.jpg




Caption: brown dog is running through the snow

/content/Flicker8k\_Dataset/244571201\_0339d8e8d1.jpg




Caption: two dogs are playing in the water

## /content/Flicker8k\_Dataset/3462454965\_a481809cea.jpg




Caption: two dogs are running in the grass

/content/Flicker8k\_Dataset/3484832904\_08619300d9.jpg



Caption: baseball player in blue and white swings ball

/content/Flicker8k\_Dataset/1897025969\_0c41688fa6.jpg



Caption: black dog is playing with multicolored stuffed animal

/content/Flicker8k\_Dataset/2419221084\_01a14176b4.jpg



Caption: two dogs are playing with each other in the grass

# /content/Flicker8k\_Dataset/1554713437\_61b64527dd.jpg



Caption: brown dog is running through the woods

/content/Flicker8k\_Dataset/3437147889\_4cf26dd525.jpg



Caption: man on motorcycle is riding on track